

# UT171A Manual of Operation

## 1、 Installation

### 1.1 System Requirements



- Pentium 1G-megahertz (MHz) processor or faster
- At least 1GB of RAM
- At least 2GB of available space on the hard disk
- USB 2.0 / 3.0 Port(s)

### 1.2 Software only supports the following operating systems:


- Microsoft Windows XP Service Pack 2 or above
- Microsoft Windows Vista service Pack 2 or above
- Microsoft Windows 7

Recommend the use of 32 bit operating system











### 1.3 Install software, Refer to the following:











## 2、The main program interface



### 2.1 The shortcut toolbar

	Connecting devices
	Disconnect the device
	To receive data, receiving continuous data
	Suspension of receiving data
	Maintain current data.
	Trigger the HZ function
	Enter the max min mode
	Set system parameters
	Software product information
	Software to help document

 Close !	Exit the software
--	-------------------

2.2 Function Options		
Menu	Screenshot	Description
Function		The corresponding instrument with the shift function
		
Range		Enter the instrument automatic or manual range
Value Model		To enter or exit the relative value model
Save Data		To enter or exit the saved data model
Read And Delete		Read or query the historical data model
		Delete some or all of the historical data

2.3 Command prompt bar: Send status command prompt

2.4 Instrument display area: Synchronous display instrument value

2.5 Table display area: The table displays the received data,  
provide the import, export, printing function.

2.6 Chart display area: The chart shows the received data, provide the save  
BMP image, refresh, print the image function.