

Service manual School balance

KERN EMB

Version 3.3
4/2009
GB



EMB-SH-e-0933



KERN EMB

Version 3.3 4/2009

Service manual

School balance

Table of Contents

1	Basic Information	3
2	Features	3
3	Calibration Procedure (CAL)	4
4	Internal Calibration Procedure (Linearity Adjustment)	5
4.1	Readout of the Internal Counts	6
5	Display Segment Test	6
6	Functional Block Diagram / Description	7
6.1	Functional Block Diagram	7
6.2	Function Description	8
7	Trouble Shooting	9
8	To Replace PCB	10
9	To Replace Load Cell Assembly	11
10	Schematics	12
10.1	For EMB 220-1, EMB 2200-0, EMB 5.2K5	12
10.2	For EMB 500-1, EMB 1200-1, EMB 5.2K1	13
10.3	For EMB 200-2, EMB 600-2	14
10.4	For EMB 100-3, EMB 1000-2	15
11	Components Layout	17
11.1	For EMB 220-1, EMB 2200-0, EMB 5.2K5	17
11.2	For EMB 500-1, EMB 1200-1, EMB 5.2K1	18
11.3	For EMB 200-2, EMB 600-2	18
11.4	For EMB 100-3, EMB 1000-2	19

1 Basic Information

Grundlegende Hinweise

The device must be repaired only by trained specialist staff or personnel with professional formation (such as a repair-specialist accredited by law concerning verification).

The service manual is obligatory for repair work.

After repair, original conditions of the device have to be restored.

Only original spare parts should be used.

Das Gerät darf nur von geschultem oder beruflich ausgebildetem Fachpersonal (z. B. eichrechtlich anerkannter Instandsetzer) repariert werden.

Die Serviceanleitung ist bindend für Reparaturen.

Das Gerät muss nach erfolgter Reparatur wieder in den Originalzustand zurückversetzt werden.

Es dürfen nur Originalersatzteile verwendet werden.

2 Features

- Auto zero
- Full Tare function
- 4 weighing units
- Display segment test function
- Negative value indication
- Auto off function (battery mode only, enable / disable)
- Zero tracking enable / disable
- Two types of Digital Auto Calibration
- Solder pads to prevent end-user internal calibration
- Low battery indicator
- Overload protection / indication
- AC adaptable
- Operated by 2 x AA size alkaline batteries (EMB220-1, EMB2200-0, EMB5.2K5), 9V battery (EMB100-3, EMB200-2, EMB600-2, EMB1000-2, EMB500-1, EMB1200-1, EMB5.2K1)

3 Calibration Procedure (CAL)

1. Turn scale on by pressing the [ON/TARE] key.
2. Press the [OFF] key for approx. 5 seconds. Display will show [CAL] and then the required calibration weight.
3. Gently place the correct calibration weight on the center on the weighing pan. Wait until display shows [F] then turn off.

In case [E] is display instead of [F], this indicates a calibration procedure error, unstable or wrong calibration weight applied for calibration. Turn the scale off and then on and repeat the procedure.

4 Internal Calibration Procedure (Linearity Adjustment)

1. Remove the top housing of the scale.
2. Connect the pads below together by soldering:
J1 for EMB 220-1, EMB 2200-0, EMB 5.2K5
J3 for EMB 100-3, EMB 500-1, EMB 1000-2, EMB 1200-1, EMB 5.2K1
J9 for EMB 200-2, EMB 600-2
3. Place scale on a hard level surface. With weighing pan installed, turn scale on. Display shall show the internal counts.

4. The internal counts shall fall in the range from **3 000 to 5 000**.

For EMB 200-2 and EMB 600-2 the internal counts shall fall in the range from **50 000 to 80 000**.

For EMB 100-3 and EMB 1000-2 the internal counts shall fall in the range from **100 000 to 300 000**.

In case out of this range, connect **J9** (**J4** for EMB 200-2 and EMB 600-2; **J6** for EMB 100-3 and EMB 1000-2) left side or right side to increase or reduce the reading.

Connecting or disconnecting pads on

J6, J7 or **J8** for EMB 220-1, EMB 2200-0, EMB 5.2K5

J5, J6, J7 or **J8** for EMB 500-1, EMB 1200-1, EMB 5.2K1

J1, J2 or **J3** for EMB 200-2, EMB 600-2

J2, J3, J4 or **J5** for EMB 100-3, EMB 1000-2

can fine tune the reading.

5. Press [OFF] key once. Display will show the required calibration weight. Place the corresponding calibration weight on the center of the weighing pan. Press [OFF] key while the weight is placed on the weighing pan.
6. Repeat step 5 for other calibration weights until display show [F] then off. Remove all weights from weighing pan.
7. Disconnect the pads below:
J1 for EMB 220-1, EMB 2200-0, EMB 5.2K5
J3 for EMB 100-3, EMB 500-1, EMB 1000-2, EMB 1200-1, EMB 5.2K1
J9 for EMB 200-2, EMB 600-2
8. Turn scale on and check the accuracy at different weight.
9. Install the top housing of scale.

In case [E] is display instead of [F], this indicates a calibration procedure error or wrong weight applied for calibration.

Turn the scale off and then on and repeat the procedure.

4.1 Readout of the Internal Counts

For example:



Without number

In that case the internal count is **66 063**



With number (here 3)

You have to set this number before the value


In that case the internal count is **321 580**

5 Display Segment Test

Whenever the scale is power on, all segments of the LCD will be turn on for approx. 5 seconds. Check for any missing segment.

6 Functional Block Diagram / Description

6.1 Functional Block Diagram



6.2 Function Description

1. **Load cell**

This is the heart of the whole system. The load cell itself is arranged as a bridge. The resistance change of the bridge elements is proportional to the load applied on the load cell. Therefore, the output of the load cell is an analog signal, which is proportional to the load applied on the scale.

2. **Amplifier**

The analog signal from the load cell is very small, of the order of micro-volt. Hence, a linear and stable amplifier is applied to amplify the analog signal to an appropriate level.

3. **A/D Converter**

In order for the analog signal can be input to the microprocessor, this part converts the analog signal to its digital equivalent. The operation of the analog to digital converter is using a SIGMA DELTA technique and under the control of the microprocessor.

4. **Microprocessor**

The microprocessor control all the functions of the scale, such as auto zero, A/D conversion, timings, weight calculation, display, overload indication, low battery indication, tare function, etc....

5. **Display**

This is the part where the weight is shown out on the LCD display in digital form. The whole display is driven by the microprocessor.

6. **Power Regulator and Low Battery Detector**

This part contains the ON/OFF power control. In order for the external power can be used by other parts of the scale, a regulator is used to regulate the supply. A low battery detector is employed to make sure that the power supply is strong enough for normal operation of the scale.

7. **Keyboard**

The keyboard provides on user interface. [On/TARE], [OFF] keys are employed to operate the scale.

7 Trouble Shooting

Power on



Full Segments?

If no display, check battery /adaptor, keys, connection between battery/adaptor—main board.

If missing segments, check fixing of LCD frame, zebra connector under LCD.



Display Zero?

If display [LO], check battery >2.6v

(>7.5v for EMB 100-3, EMB 200-2, EMB 600-2, EMB 500-1, EMB 1000-2, EMB 1200-1, EMB 5.2K1)

adaptor >9v.

If display [E] , check internal count.



Proper readout?

If unstable reading, check weighing plate, overload stopper, load cell and wires, environmental conditions and stable table.



Correct reading?

If not accurate, perform internal calibration.

If cannot reach full capacity, check weighing plate, overload stopper, load cell and internal zero point.

If always zero, check internal zero point. Internal calibration if necessary.



Normal operation.

8 To Replace PCB

1. Disassemble top housing of scale.
2. Disconnect

PL1, SS1 and **flat line** of keyboard (EMB 220-1, EMB 2200-0, EMB 5.2K5)

PL1, PL2 and **PL3** (EMB 500-1, EMB 1200-1, EMB 5.2K1)

PL1, PL2 and **JP1** (EMB 200-2, EMB 600-2)

PL1, PL3, JP2, J1 (flat line) and **SENSOR** (EMB 100-3, EMB 1000-2)

from the PCB. Disassemble the PCB screw.

Replace a new PCB. Assemble the PCB screw and connect the cables and the flat line again.

3. Perform internal calibration as described in section 4.
4. Assemble the top housing.
5. Check accuracy of scale at different weight.

EMB 200-2		EMB 600-2		EMB 220-1		EMB 500-1	
weight (g)	tol. (g)	weight (g)	tol. (g)	weight (g)	tol. (g)	weight (g)	tol. (g)
50.00	0.02	100.00	0.02	50.0	0.2	100.0	0.3
100.00	0.02	200.00	0.02	100.0	0.2	300.0	0.3
150.00	0.02	400.00	0.04	150.0	0.2	500.0	0.3
200.00	0.02	600.00	0.06	200.0	0.2		
EMB 1200-1		EMB 2200-0		EMB 5.2K1		EMB 5.2K5	
weight (g)	tol. (g)	weight (g)	tol. (g)	weight (g)	tol. (g)	weight (g)	tol. (g)
200.0	0.3	500	2	1000	3	1000	10
500.0	0.3	1000	2	3000	3	3000	10
1000.0	0.3	1500	2	5000	3	5000	10
1200.0	0.3	2000	2				
EMB 100-3				EMB 1000-2			
weight (g)		tol. (g)		weight (g)		tol. (g)	
10.000		0.002		100.00		0.02	
20.000		0.002		200.00		0.02	
50.000		0.003		500.00		0.03	
70.000		0.003		700.00		0.03	
100.000		0.003		1000.00		0.03	

6. Check other functions, such as Tare and Auto-Off.

9 To Replace Load Cell Assembly


1. Disassemble top housing of scale.
2. Disconnect the load cell wires from main PCB. Remove the screws fixing the bottom plate of the load cell assembly. Replace the load cell with a new one. Connect the load cell wires and fix the screws.
3. Perform internal calibration as described in section 4.
4. Assemble the top housing.
5. Check accuracy of scale at different weight.

EMB 200-2		EMB 600-2		EMB 220-1		EMB 500-1	
weight (g)	tol. (g)	weight (g)	tol. (g)	weight (g)	tol. (g)	weight (g)	tol. (g)
50.00	0.02	100.00	0.02	50.0	0.2	100.0	0.3
100.00	0.02	200.00	0.02	100.0	0.2	300.0	0.3
150.00	0.02	400.00	0.04	150.0	0.2	500.0	0.3
200.00	0.02	600.00	0.06	200.0	0.2		
EMB 1200-1		EMB 2200-0		EMB 5.2K1		EMB 5.2K5	
weight (g)	tol. (g)	weight (g)	tol. (g)	weight (g)	tol. (g)	weight (g)	tol. (g)
200.0	0.3	500	2	1000	3	1000	10
500.0	0.3	1000	2	3000	3	3000	10
1000.0	0.3	1500	2	5000	3	5000	10
1200.0	0.3	2000	2				
EMB 100-3				EMB 1000-2			
weight (g)		tol. (g)		weight (g)		tol. (g)	
10.000		0.002		100.00		0.02	
20.000		0.002		200.00		0.02	
50.000		0.003		500.00		0.03	
70.000		0.003		700.00		0.03	
100.000		0.003		1000.00		0.03	


6. Check other functions, such as Tare and Auto-Off.

10 Schematics

10.1 For EMB 220-1, EMB 2200-0, EMB 5.2K5




10.2 For EMB 500-1, EMB 1200-1, EMB 5.2K1




REVISIONS		
ZONE	REV.	DESCRIPTION

TITLE: SCHEMATIC	
MODEL NO.	914-12
PART NO.	505-09184
MATERIAL	FINISH
SCALE	DO NOT SCALE DIMING
SHEET	OF

10.3 For EMB 200-2, EMB 600-2



10.4 For EMB 100-3, EMB 1000-2




REVISIONS		DATE	APPROVED
ZONE	REV	DESCRIPTION	
0		INITIAL RELEASE	

TYPED OR DRAWN		DATE	
APPROVED		DATE	



TITLE			
SCHEMATIC			
MODEL NO.	XXX-00914	PART NO.	SCSE-091410-000
DESIGNED		INCHK	
APPROVED			

DO NOT SCALE DRAWING	SHEET 1 OF 1
----------------------	--------------




11 Components Layout

11.1 For EMB 220-1, EMB 2200-0, EMB 5.2K5




11.2 For EMB 500-1, EMB 1200-1, EMB 5.2K1





MODEL	R9
EMB 500-1	68K
EMB 1200-1	30K
EMB 5.2K1	150K


11.3 For EMB 200-2, EMB 600-2



11.4 For EMB 100-3, EMB 1000-2



REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED



model	R7	C38
942-01	220	0.47uF
942-02	220	0.47uF
942-13	330	0.1uF
942-14	330	0.1uF
942-25	330	0.1uF
942-26	330	0.1uF

TOLERANCE UNLESS OTHERWISE SPECIFIED ANGLES SHOULD BE 45 DEGREES UNLESS NOTED DIMENSIONS IN MILLIMETERS DRAWN BY: [Symbol]		TITLE: D/S PCB COMPONENT LAYOUT	
CHECKED	MODEL NO. XXX000-321	PART NO.	5052-032111-000
APPROVED	MATERIAL	FINISH	
UNIT	MM	SCALE	DO NOT SCALE DRAWING
			SHEET OF