KERN BALANCES & TEST SERVICES CATALOGUE 2019

Counting scale KERN CXB · CXB-NM





Note: Official verification duty for commercial trade

Entry level model into professional counting, also with EC type approval [M], counting resolution of 30,000 points

Features

- **Precise counting:** The automatic reference weight optimisation of reference weight gradually improves the average piece weight value
- Programmable using numerical key pad: - required reference quantity
- known reference weight
- **Three displays** for weight display (verifiable), reference weight, total pieces
- Audible Fill-to-target: target quantity or target weight can be programmed, e. g. for checkweighing. When the target value is reached, a signal will sound
- · 10 Memories for reference weights
- Counting results memory: adds up all individual piece counts, result is shown in total weight and total pieces

- Energy management: Backlight turns off after 5 s
- **PRE-TARE function** for manual subtraction of a known container weight, useful for checking fill-levels
- Two balances in one: Changes from counting mode to weighing mode at the touch of a key
- Protective working cover included with delivery
- Internal rechargeable battery pack included
 with delivery

Technical data

- Large backlit LCD displays, digit height 18 mm
 Dimensions weighing surface, stainless
- steel, W×D 300×225 mm
- Dimensions housing W×D×H, 300×330×110 mm
- Rechargeable battery pack internal, operating time up to 200 h without backlight, charging time approx. 8 h
- Permissible ambient temperature -10 °C/40 °C

Accessories

- **Protective working cover**, scope of delivery: 5 items, KERN CXB-A01S05
- Rechargeable battery pack internal, operating time up to 200 h without backlight, charging time approx. 8 h, KERN GAB-A04

STANDARD						OPTION	FACTORY
CAL EXT	SUM	ACCU	 230 V	DMS	1 DAY	DAkks +3 Days	+3 DAYS

Model	Weighing	Readability	Verification	Minimal	Smallest part	Counting	Net weight		Option			
	capacity		value	load	weight	resolution			Verification		DAkkS Calibr. Certificate	
	[Max]	[d]	[e]	[Min]	[Normal]		approx.		MIII		DAkkS	
KERN	kg	g	g	g	g/piece	Points	kg		KERN		KERN	
CXB 3K0.2	3	0,2	-	-	1	30.000	4,0		-		963-127	
CXB 6K0.5	6	0,5	-	-	2	30.000	4,0		-		963-128	
CXB 15K1	15	1	-	-	5	30.000	4,0		-		963-128	
CXB 30K2	30	2	-	-	10	30.000	4,2		-		963-128	
Note: For applications that require verification, please order verification at the same time, initial verification at a later date is not possible.												
Verification at the factory, we need to know the full address of the location of use.												
CXB 3K1NM	3	1	1	20	1	30.000	4,0		965-227		963-127	
CXB 6K2NM	6	2	2	40	2	30.000	4,2		965-228		963-128	
CXB 15K5NM	15	5	5	100	5	30.000	4,0		965-228		963-128	
CXB 30K10NM	30	10	10	200	10	30.000	4,2		965-228		963-128	

KERN & SOHN GmbH · Ziegelei 1 · 72336 Balingen · Germany · Tel. +49 7433 9933-0 · Fax +49 7433 9933-146 · www.kern-sohn.com · info@kern-sohn.com

KERN BALANCES & TEST SERVICES CATALOGUE 2019

PROTOCOL



Pictograms

Internal adjusting:

Quick setting up of the balance's accuracy with CAL INT internal adjusting weight (motordriven)

Adjusting program CAL:

For quick setting up of the balance's accuracy. External adjusting weight required



CAL EXT

Easy Touch:

Suitable for the connection, data transmission and control through PC, tablet or smartphone Memory:

Balance memory capacity, e.g. for article data, MEMORY weighing data, tare weights, PLU etc.

Alibi memory: Secure, electronic archiving of weighing results,

ALIBI complying with the 2014/31/EU standard.

Data interface RS-232:

• 6550 • To connect the balance to a printer, PC or RS 232 network

RS-485 data interface:

To connect the balance to a printer, PC or other RS 485 peripherals. Suitable for data transfer over large distances. Network in bus topology is possible



• 6534 •

USB data interface:

To connect the balance to a printer, PC or other peripherals



Bluetooth* data interface:

To transfer data from the balance to a printer, PC or other peripherals



WLAN data interface:

To transfer data from the balance to a printer, PC or other peripherals



Control outputs (optocoupler, digital I/O): To connect relays, signal lamps, valves, etc.

Analogue interface:

to connect a suitable peripheral device for analogue processing of the measurements



ANALOG

For direct connection of a second balance

Interface for second balance:



Network interface: For connecting the scale to an Ethernet network



Wireless data transfer:

between the weighing unit and the evaluation unit using an integrated radio module

*The Bluetooth[®] word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by KERN & SOHN GmbH is under license. Other trademarks and trade names are those of their respective owners.

KERN – Precision is our business

To ensure the high precision of your balance KERN offers you the the appropriate test weight in the international OIML error limit classes E1-M3 from 1 mg - 2500 kg. In combination with a DAkkS calibration certificate the best pre-requisite for proper balance calibration.


The KERN DAkkS calibration laboratory today is one of the most modern and bestequipped DAkkS calibration laboratories for balances, test weights and force-measurement in Europe.

Thanks to the high level of automation, we can carry out DAkkS calibration of balances, test weights and force-measuring devices 24 hours a day, 7 days a week.

Range of services:

- · DAkkS calibration of balances with a maximum load of up to 50 t
- · DAkkS calibration of weights in the range of 1 mg 2500 kg · Volume determination and measuring of magnetic susceptibility (magnetic
- characteristics) for test weights · Database supported management of checking equipment and reminder service
- · Calibration of force-measuring devices
- · DAkkS calibration certificates in the following languages DE, GB, FR, IT, ES, NL, PL
- · Conformity evaluation and reverification of balances and test weights





weight, date and time, regardless of a printer connection

KERN Communication Protocol (KCP):

It is a standardized interface command set for

KERN balances and other instruments, which

parameters and functions of the device. KERN

devices featuring KCP are thus easily integrated

allows retrieving and controlling all relevant



With weight, date and time. Only with KERN PRINTER printers

Piece counting:

PCS

Reference quantities selectable. Display can be switched from piece to weight

Recipe level A:

The weights of the recipe ingredients can be added together and the total weight of the recipe can be printed out

Recipe level B:

Internal memory for complete recipes with name and target value of the recipe ingredients. User guidance through display

Recipe level C:



Internal memory for complete recipes with name and target value of the recipe ingredients. User guidance through display, multiplier function, adjustment of recipe when dosages are exceeded or barcode recognition

Totalising level A:

The weights of similar items can be added SUM together and the total can be printed out




TOL

Percentage determination:

Determining the deviation in % from the target value (100 %)


Weighing units: C





Weighing with tolerance range: ○ 3)

(Checkweighing) Upper and lower limiting can be programmed individually, e.g. for sorting and dosing. The process is supported by an audible or visual signal, see the relevant model

Hold function:







Stainless steel:

The balance is protected against corrosion

Suspended weighing:

Load support with hook on the underside of the balance

Battery operation:

Ready for battery operation. The battery type is BATT specified for each device



ΙΝΟΧ

Rechargeable battery pack: Rechargeable set



Universal mains adapter:

with universal input and optional input socket adapters for A) EU, CH; B) EU, CH, GB, USA; C) EU, CH, GB, USA, AUS

Mains adapter:

230V/50Hz in standard version for EU. On 230 V request GB, USA or AUS version available

Power supply:



Integrated in balance. 230V/50Hz standard EU. More standards e.g. GB, USA or AUS on request



Weighing principle: Strain gauges Electrical resistor on an elastic deforming body

Weighing principle: Single cell technology:

The time required for verification is specified in

Advanced version of the force compensation

principle with the highest level of precision

The time required for DAkkS calibration is

The time required for internal shipping

The time required for internal shipping

preparations is shown in days in the pictogram

preparations is shown in days in the pictogram



s T

SC TECH

Μ

+3 DAYS

DAkkS

+3 DAYS

1 DAY

2 DAYS

Your KERN specialist dealer:

Impex Produkter AS

1363 Høvik

www.impex.no

info@impex.no

Tel.: 22 32 77 20

Gamle Drammensvei 107

Weighing principle: Tuning fork: A resonating body is electromagnetically

excited, causing it to oscillate

Weighing principle: Electromagnetic force compensation

FORCE Coil inside a permanent magnet. For the most accurate weighings

Verification possible:

Package shipment:

Pallet shipment:

DAkkS calibration possible:

shown in days in the pictogram

the pictogram