

Floor scale KERN BFN











Stainless steel weighing bridge with screwed-on weighing plate (IP68) and stainless steel display device (IP65), with EC type approval [M]

## **Features**

- · Tough industry standard suitable for use in harsh industrial applications
- · Weighing plate screwed on from the top, with stainless steel screws, so it's easy to remove, hygienic and easy to clean
- 11 Weighing bridge: stainless steel, extremely resistant to bending due to material thickness, 4 welded stainless steel load cells, dust and spray protection IP68. Weighing bridge can also be delivered as component without the display device, for details see KERN KFP-V40
- · Your support in a HACCP-compliant quality system
- · Easy levelling of the weighing bridge as well as access to the junction box from above
- 2 Display device: stainless steel, protection against dust and water splashes IP65, for industrial applications, hygienic and easy to clean, integrated power supply, The display device can also be delivered as a component without the weighing bridge, for details see KERN KFN-TM
- Benchtop stand incl. wall mount for display device as standard

- Totalising of weights and piece counts
- 3 Did you know? Our floor scales are delivered in a robust wooden box. This protects the high-quality weighing technology from environmental influences and stresses during transportation. KERN - always one step ahead

#### **Technical data**

- · Large backlit LCD display, digit height 52 mm
- Dimensions of display device W×D×H 266×165×96 mm
- · Cable length of display device approx. 5 m
- Weighing plate dimensions W×D×H ■ 1000×1000×85 mm
- **I** 1500×1200×80 mm
- · Rechargeable battery pack internal, operating time up to 35 h without backlight, charging time approx. 12 h
- · Permissible ambient temperature -10 °C/40 °C

## **Accessories**

- 4 Stand to elevate display device, height of stand approx. 800 mm, KERN YKP-02
- · Pair of base plates to fix the weighing bridge to the floor, KERN BFN-A03
- 5 Ascending ramp, stainless steel, not included, for models with weighing plate size KERN BFN-A05 KERN BFN-A01
- 6 Stable pit frame, stainless steel, for models with weighing plate size KERN BFN-A06 KERN BFN-A02
- · Data interface RS-232, interface cable included, approx. 1,5 m, must be ordered at purchase, KERN KFN-A01
- · Cable with special length 15 m, between display device and platform, for verified models which must be ordered at the time of purchase, KERN BFB-A03
- · Further details, plenty of further accessories and suitable printers see Accessories

Note: For verified scales the weighing bridge must be fixed to the floor. Optionally, with an access ramp, a footplate pair or a pit frame

Shipment via freight forwarder. Please ask for dimensions, gross weight, shipping costs

963-130

963-132

965-230

965-232

STANDARD



BFN 1.5T0.5M

BFN 3T-3M









1500

3000







0.5



10

20







В



	2	1							
Model	Weighing	Readability	Minimal load	Net weight	Weighing plate	Option			
	capacity	= Verification value				Verification D		DAkkS Calibr. Certificate	
	[Max]	[d] = [e]	[Min]	approx.		MIII		DAkkS	
KERN	kg	kg	kg	kg		KERN		KERN	
BFN 600K-1SM	600	0,2	4	100	Α	965-230		963-130	
REN 1T-/CM	1500	0.5	10	100	۸	065 230		063 130	

Note: For applications that require verification, please order verification at the same time, initial verification at a later date is not possible. Verification at the factory, we need to know the full address of the location of use.

135

135

# **KERN BALANCES & TEST SERVICES CATALOGUE 2019**



## **Pictograms**



#### Internal adjusting:

Quick setting up of the balance's accuracy with internal adjusting weight (motordriven)



#### Adjusting program CAL:

For quick setting up of the balance's accuracy. External adjusting weight required



#### Easy Touch:

Suitable for the connection, data transmission and control through PC, tablet or smartphone



#### Memory:

Balance memory capacity, e.g. for article data, weighing data, tare weights, PLU etc.



#### Alibi memory:

Secure, electronic archiving of weighing results, complying with the 2014/31/EU standard.



## Data interface RS-232:

To connect the balance to a printer, PC or network



## RS-485 data interface:

To connect the balance to a printer, PC or other peripherals. Suitable for data transfer over large distances. Network in bus topology is possible



#### **USB** data interface:

To connect the balance to a printer, PC or other peripherals



#### Bluetooth\* data interface:

To transfer data from the balance to a printer, PC or other peripherals



## WLAN data interface:

To transfer data from the balance to a printer, PC or other peripherals



## Control outputs (optocoupler, digital I/O):

To connect relays, signal lamps, valves, etc.



## Analogue interface:

to connect a suitable peripheral device for analogue processing of the measurements



# Interface for second balance:

For direct connection of a second balance



## Network interface:

For connecting the scale to an Ethernet network



## Wireless data transfer:

between the weighing unit and the evaluation unit using an integrated radio module

\*The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by KERN & SOHN GmbH is under license. Other trademarks and trade names are those of their respective owners.

## KCP PROTOCOL

#### **KERN Communication Protocol (KCP):**

It is a standardized interface command set for KERN balances and other instruments, which allows retrieving and controlling all relevant parameters and functions of the device. KERN devices featuring KCP are thus easily integrated with computers, industrial controllers and other digital systems



## GLP/ISO log:

The balance displays serial number, user ID, weight, date and time, regardless of a printer connection



## GLP/ISO log:

With weight, date and time. Only with KERN printers



## Piece counting:

Reference quantities selectable. Display can be switched from piece to weight



## Recipe level A:

The weights of the recipe ingredients can be added together and the total weight of the recipe can be printed out



## Recipe level B:

Internal memory for complete recipes with name and target value of the recipe ingredients. User guidance through display



## Recipe level C:

Internal memory for complete recipes with name and target value of the recipe ingredients. User guidance through display, multiplier function, adjustment of recipe when dosages are exceeded or barcode recognition



## Totalising level A:

The weights of similar items can be added together and the total can be printed out



## Percentage determination:

Determining the deviation in % from the target value (100 %)



## Weighing units:

Can be switched to e.g. nonmetric units at the touch of a key. See balance model. Please refer to KERN's website for more details



## Weighing with tolerance range:

(Checkweighing) Upper and lower limiting can be programmed individually, e.g. for sorting and dosing. The process is supported by an audible or visual signal, see the relevant model



MOVE

## Hold function:

(Animal weighing program) When the weighing conditions are unstable, a stable weight is calculated as an average value



## Protection against dust and water splashes IPxx:

The type of protection is shown in the pictogram.



#### Stainless steel:

The balance is protected against corrosion



#### Suspended weighing:

Load support with hook on the underside of the



#### **Battery operation:**

Ready for battery operation. The battery type is specified for each device



## Rechargeable battery pack:

Rechargeable set



#### Universal mains adapter:

with universal input and optional input socket adapters for A) EU, CH; B) EU, CH, GB, USA; C) EU, CH, GB, USA, AUS



#### Mains adapter:

230V/50Hz in standard version for EU. On request GB, USA or AUS version available



#### Power supply:

Integrated in balance. 230V/50Hz standard EU. More standards e.g. GB, USA or AUS on request



#### Weighing principle: Strain gauges

Electrical resistor on an elastic deforming body



## Weighing principle: Tuning fork:

A resonating body is electromagnetically excited, causing it to oscillate



# Weighing principle: Electromagnetic force compensation

Coil inside a permanent magnet. For the most accurate weighings



## Weighing principle: Single cell technology:

Advanced version of the force compensation principle with the highest level of precision



## Verification possible:

The time required for verification is specified in the pictogram



# DAkkS calibration possible:

The time required for DAkkS calibration is shown in days in the pictogram



# Package shipment:

The time required for internal shipping preparations is shown in days in the pictogram



## Pallet shipment:

The time required for internal shipping preparations is shown in days in the pictogram

# KERN - Precision is our business

To ensure the high precision of your balance KERN offers you the the appropriate test weight in the international OIML error limit classes E1-M3 from 1 mg - 2500 kg. In combination with a DAkkS calibration certificate the best pre-requisite for proper

The KERN DAkkS calibration laboratory today is one of the most modern and bestequipped DAkkS calibration laboratories for balances, test weights and force-measure-

ment in Europe.

Thanks to the high level of automation, we can carry out DAkkS calibration of balances, test weights and force-measuring devices 24 hours a day, 7 days a week.

## . . .

- DAkkS calibration of balances with a maximum load of up to 50 t
- DAkkS calibration of weights in the range of 1 mg 2500 kg
- Volume determination and measuring of magnetic susceptibility (magnetic characteristics) for test weights
- Database supported management of checking equipment and reminder service
- Calibration of force-measuring devices
- DAkkS calibration certificates in the following languages DE, GB, FR, IT, ES, NL, PL
- Conformity evaluation and reverification of balances and test weights

# Your KERN specialist dealer:

Impex Produkter AS
Gamle Drammensvei 107
1363 Høvik
www.impex.no
info@impex.no
Tlf.: 22 32 77 20